

## Beechcraft B1900D Startup:

Most required switches are activated by left clicking on them with the mouse. Press 'Control C' in Flightgear to view mouse clickable spots.

Startup:



- Mouse click BATT , L GEN & R GEN switches:
- Turn on AVIONICS switch:
- (Switches are on the left hand side of pilot's yoke – pull yoke back if switches are not visible.)



- 
- Turn on Master Panel Lights switch:
- Turn Pilot Flight Lights, Engine Instrument Lights and Edgelight Panel Lights as required to brighten/dim panel lights:
- Turn on Landing , Taxi , Nav , Beacon & Strobe lights as required:

File View Location Autopilot Weather Equipment ATC/AI Debug Help



- Push Condition and Prop levers all the way forward (click on the top of the slots):
- Press Shift B , emergency brakes will be on , and you are ready for flight!

## GPS

- Press 'Shift P' to display the on screen GPS unit:



- 
- The GPS unit currently only displays several NAV modes (waypoint information). Other features will be added in the future.



- 
- Open the [Equipment] [GPS Settings] menu and add your destination in WP 1;
- Your course is then displayed on the GPS. Click inside the inner circle on the GPS's left hand knob to display different NAV information.
- Click the center white button (Direct To ) to recalculate your course during flight.
- The [HELP] menu will show keys for other controls :
- Enjoy your flight!